


Rear Floor

THEICONIC FORD FAILGON AND GIT



POST-APOCALYPTIC EDITION



YOUR MODEL

You will be building a 1:8 scale replica of a customised 1973 Ford Falcon XB GT. Features include a lift-up bonnet that reveals a detailed engine, opening doors, wind-down windows and an 'active' steering wheel. A remote-control fob illuminates the main lights, brake lights and indicators.

Scale: 1:8 Length: 62cm Width: 25cm Height: 19cm Weight: 7+kg



Ford Motor Company trademarks and trade dress used under licence to GRE for Groupe ELIGOR

Official
Licensed Product

CUSTOMER SERVICE, SUBSCRIPTIONS & BACK ORDERS

Please visit hachettepartworks.com/contact to get in touch.

Published by Hachette Partworks Ltd 4th Floor, Jordan House, 47 Brunswick Place, London, N1 6EB www.hachettepartworks.com

Hachette PARTWORKS LTD

© 2026 Hachette Partworks Ltd
© 2026 Ford Motor Company
Distributed in the UK and Republic of Ireland by Marketforce.
Printed in the United Kingdom
ISSN 2076 F811

Complete in 130 issues

ALL RIGHTS RESERVED

Items may vary from those shown.
All parts belong to a kit. Collectors' item for adults. Not suitable for children under 14. Some parts may have sharp edges, please handle them with care.

The installation of electronic parts must always be carried out by an adult. When replacing batteries, use the same type of batteries. Please ensure that the battery compartment is securely fastened before you use the model again. Used batteries should be recycled. Please make sure to check with your local council how batteries should be disposed of in your area. Batteries can present a choking danger to small children and may cause serious harm if ingested. Do not leave them lying around and keep any spare batteries locked away at all times.

The editor's policy is to use papers that are natural, renewable and recyclable products and made from wood grown in sustainable forests. The logging and manufacturing processes are expected to conform to the environmental regulations of the country of origin.

In the event of a significant increase in production and transport costs, the publisher reserves the right to modify its selling prices.

MANAGING DIRECTOR – Isabelle Couderc
EDITORIAL DIRECTOR – Helen Nally
MARKETING DIRECTOR – Elise Windmill
PRODUCTION DIRECTOR – Sema Sant Anna
SENIOR PRODUCTION MANAGER – Lee Matthews
MANAGING EDITOR – Sarah Gale
PROJECT EDITOR – Gary Webb
DISTRIBUTION MANAGER – Paul Smith
PRODUCT MANAGER – Rhys Myner



For our environmental policy in full please scan the



NOT SUITABLE FOR CHILDREN
UNDER THE AGE OF 14.
This product is not a toy and is
not intended for use in play.

Editorial and design: Windmill Books Ltd

Picture credits: Front cover: Jess Esposito and David Burton: main; Richard Bryden: bl, Shutterstock: Steven Giles background.

Step-by-step photography: Richard Bryden Model photography: Jess Esposito and David Burton

Windmill Books have made every attempt to contact the copyright holder, if you have any information please contact Sophie Mortimer: smortimer@windmillbooks.co.uk

Stage 71: Rear Floor

Self-adhesive carpet felt is fitted to the rear floor panel, and the rear floor is fixed to the front floor.



List of parts:

71A Rear floor

71B Left seat belt retractor

71C Right seat belt retractor


71D Self-adhesive carpet felt

PS05 Six* 2.3 x 4mm PB screws

*Including spare PB = Pan head for plastic




Stage 71: Rear Floor




CARPET PANELS

Identify the sections A, B, C, D and E on the self-adhesive carpet felt panel **71D**. **NOTE:** Only remove the panels from the backing as you need them when following the steps.




STEP 1

Remove panel A from backing sheet 71D. Starting from the front left side, carefully fix it to floor panel 71A. Start by aligning the straight edges along the front edge of the floor and against the transmission hump (as indicated by yellow lines, above). Wrap the felt up the raised edge along the left-hand edge and over the flat lip.




STEP 2

At the back edge, smooth the carpet felt up against the raised side of the foot well.




STEP 3

Similarly, smooth panel **B** in place on the right side of the rear floor **71A**.




STEP 4

Take strip **c** from the felt **71D** and align the long straight edge of strip **c** with the edge of the raised lip on the left-hand side of the floor panel (indicated by the yellow line).



STEP 5

Gently smooth the section in place along the vertical side of the lip and across the base of the channel. You may find it helpful to use the stem of a screwdriver or similar to push the felt into the angle of the channel.





STEP 6

Repeat to stick section **D** in place on the right-hand side of the floor panel.




Stage 71: Rear Floor






STEP 9 Fit the right retractor 71C into the socket on the right-hand side of the floor panel 71A.




STEP 10

Holding part **71C** in place, turn the assembly over and fix the retractor **71C** in place with a **PS05** screw.



STEP 1

Similarly, fit the left retractor **71B** in place on the left-hand side of the floor panel **71A** and fix in place with a **PS05** screw.



STEP 12

Take the assembly from the previous issue and check how the front edge of the rear floor **71A** fits against the rear edge of the front floor **69A**.



STEP 13

When you are happy with the fit, fix the floor sections together from the underside with four **PS05** screws (circled).



COMING IN ISSUE 72



ASSEMBLY GUIDE

Self-adhesive felt is fitted to the seat back panel, along with two supports, and the seat panel is attached to the floor assembly.

HISTORY OF THE FORD FALCON

After the successful launch of Ford's two-door 'Simple Machine' in 1969, the Mayerick range expanded rapidly and Ford produced two Maverick-based concept cars.

NEW PARTS

Rear seat back panel supports, rear seat back panel, selfadhesive felt and screws.



Published weekly UK: £10.99 AUS: \$21.99



